

Electronic pulse Massager

USER MANUAL



(1) Features:

You can choose any of the treatment modes Shoulder/waist/joint button/foot)

The product is specially designed for lessening pain in muscles. The apparatus can produce curative effect particularly to the patients suffering from the pain in neck, back, loin and various joints. The exclusively designed program consists of different waves through alternative composition, giving a feeling of manual massage by hand. The soft and gentle pulse can improve the blood circulation and promote main and collateral channels unblocked and give a special effect on releasing fatigue. Use pulse massager for: Stiffness of shoulders. Paralysis of peripheral nerves. Recovery of fatigue. Improves blood circulation neuralgia. Gradual release of muscular pain.

(2) Technical data:

1. Voltage: 4.5V
 2. Rated working time: 15min
 3. Accessories: 1pcs monitor/ 2pcs sticker pads/ 1 set of wire
- Optional accessories : 2pcs magnetism shoes/1pcs massage blinder

(3) preparing & setting the electrodes.

1. Correctly connect the electrode cord to the electrode pads or magnetism shoes.

2. Insert the plug of the electrode cord into the unit' electrode jack.
 3. Pell off the film from the electrode pads.
 4. Use a damp towel to wipe the area of skin on which you will be affixing the pads to remove any oil, cosmetic or dirt.
 5. Should the electrode pads be soiled, both their adhesiveness and the number of times of possible use will be reduced.
 6. Apply the electrode pads to the area of the body you wish to massage.
- The unit can't operate unless both pads from at least one change are applied.

(4) Button description: Total 13 buttons

Optional accessories



1. **“Shoulder” button:** suit for massage on shoulder and back. Press speed “+”/”-“ button to adjust the intensity. And speed is automatically reduced or increased. It takes 30 minutes to complete a full treatment. Transfer mode per 5 minutes (PRESS->RUB->VIBRATE->THUMP).
2. **“Waist” button:** designed for waist massage. Waist massage state will be shown on screen. And change mode per 5 minutes (PRESS->RUB->VIBRATE->THUMP), Press speed “+”/”-“ button to

- adjust the intensity.
3. **“Joint” button:** designed for joint massage. change mode per 5 minutes(PRESS->RUB->VIBRATE->THUMP), Press speed “+”/ “-” button to adjust the intensity
 4. **“Hand&Foot” button** suitable for hand and foot massager. The state of hand and foot massage state can be changed per 5 minutes. Total 4 modes(PRESS->RUB->VIBRATE->THUMP).
 5. **“Leg”Button:** adjust to leg massage, Massage mode change every 5 minutes Press speed “+”/“-” button to adjust the intensity. And speed is automatically reduced or increased.
 6. **Repeat button:** It is useful only under the state of above 5 states press this button to repeat above 5 different massage function.
 7. The massage time displayed on screen
 8. The massage speed displayed on screen.
 9. **Speed & Intensity:** both include high(+) & low(-) button. Press high button to increase grade, Press Low button to reduce grade.
 10. **“Thump” button:** Press it to start to thump massage.
 11. **“Vibrate” button:** Press it to start to vibration massage.
 12. **“Rub” button:** Press it to start to rub massage.
 13. **“Press” button:** Press it to start to press massage.
 14. **ON/OFF:** turn on the button to start the device, turn off to stop working.there are 8 grades for electronic intensity.

(5) Trouble shooting:

Problem check and remedy.

No stimulation at all.

1. Are the pads and the cord connected properly?

Check the connection to make sure it is correct.

2. Are the electrodes set properly?

See before instructions on how to set them properly

3. Have the batteries run down?

If so, replace them with new ones.

4. Are the batteries installed properly?

See before instructions on how to insert them properly.

The display and treatment mode light up but there is no stimulation

1. Are the electrodes set properly?

The power to the connected channel automatically turns off approx.

10 seconds if one of the two electrode pads is removed from the skin,

Therefore, set them closely to your skin.

2. The Intensity level is at what position?

Press on the intensity control button and stop at a point where there is moderate stimulation.

3. Are the electrode pads overlapping?

Affix the pads so that they do not overlap in any way.

Weak stimulation

1. Are the electrode pads overlapping?

Affix the pads so that they do not overlap in any way.

2. Are the pads and the cord connected properly?

Check the connections to make sure they are correct.

3. Are the electrodes set properly?

See before instructions on how to set them properly.

Neither the display nor the treatment modes lights up when the power is turn on.

1. Have the batteries run down?

When the batteries run down, the unit automatically turns off.

Replace the batteries with new ones.

2. Are the batteries correctly installed?

See before instructions on how to insert them properly.

Skin turns red.

1. Is the treatment time too long?

Limit your treatment time to 10-15 minutes

2. Have the pads dried?

Wet the surface of the pads and try again. If that does not solve the problem or if the pads are quite soiled, replace them with new ones.

3. Are the pads affixed firmly?

Set them so that they fit closely to your skin.(7) **WARNING**

(6)USER GUIDE

Battery and Adapter cannot be used at the same time,
Remember to remove the battery when using the
Adapter,If not, it will easily damage the machine.

